

Note "spindles" = these shocks are designed for OEM replacement, 1" spring or spindle only lowerings
 Note "springs" = for any 2-3" spring or 2-5" spring/spindle lowering we recommend shorter shocks

BELLTECH Shock Absorbers									
		FRONT Shocks				REAR Shocks			
YEAR	MODEL	DESIRED LOWERING		ND2	SP	DESIRED LOWERING		ND2	SP
		FRONT	NOTES	Part#	Part#	REAR	NOTES	Part#	Part#
Chevrolet Colorado Applications									
04-12	Colorado / Canyon All Cabs w/ ZQ8 Suspension	0"-2"	ball joint		25005	0-3"	blocks	8530	2210IF
		2"-4"	springs		25005	3-5"	leaves	8525	2208IF
Chevrolet S-Series 2 WD Applications									
82-04	S10 / S15 Std. & Ext. Cab Pickup Only (4 & 6 Cyl.) S-10 Blazer / Jimmy / Extreme	0"-2"	spindles	8017	10102I	0-3"	blocks	8502	2412IF
		2"-5"	springs	8007	10101I	3-5"	leaves	8530	2410IF
Chevrolet S-Series 4 WD Applications									
82-04	S-10 / S-15 Pickup / Blazer Incl. Typhoon & Syclone	1"-3"	keys	8520	2105DD	1-3"	blocks	8502	2412IF
						1-3"	leaves	8530	2410IF
Chevrolet 1/2 Ton Fullsize Truck 2 WD Applications									
2014-	1/2-Ton Silverado/Sierra (All Cabs) (struts offer 2" lift to 2" lowering function in 1/2" increments)					0-1"		8536	2214FF
						2-4"		8504	2212FF
						5-7"		8510	2210FF
07-13	1/2-Ton Silverado/Sierra (All Cabs) (struts offer 2" lift to 2" lowering function in 1/2" increments)	+2" to -2"	OEM springs		25003	0-1"		8536	2214FF
		1"-4"	spindles		25003	2-4"		8504	2212FF
						5-7"		8510	2210FF
05-06	1/2-TON Silverado Std & Ext. Cab Short Bed Only (with factory equip. front torsion bar)	0"-2"	spindles	8521	310400	0-1"		8536	2214FF
		2"-5"	keys	8521	310400	2-4"		8504	2212FF
						5-6"		8510	2209FF
04-06	1/2-TON Silverado CREW CAB (4DR)	0"-2"	spindles	8014	10104I	0-1"		8536	2214FF
		2"-5"	springs	8000	10103I	2-4"		8504	2212FF
						5-7"		8510	2209FF
03-06	Silverado 1500 SS / Denali Sierra (AWD) Incl. 01" GMC Sierra C3	0"-2"	spindles	8521	310400	0-1"		8536	2214FF
		2"-4"	keys	8521	310400	2-4"		8504	2212FF
99-06	1/2-TON Silverado Std. & Ext. Cab Short Bed Only (with factory equip. front coil spring)	0"-2"	spindles	8014	10104I	0-1"		8536	2214FF
		2"-5"	springs	8000	10103I	2-4"		8504	2212FF
						5-7"		8510	2209FF
88-98	1/2-TON C-1500 Std & Ext. Cab	0"-2"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-4"	springs	8006	10102I	2-4"		8535	2214IF
						5-7"		8502	2212IF
90-94	1/2-TON C-1500 SS-454 ONLY.	0"-2"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-7"		8502	2212IF
73-87	1/2-TON C-10 Pickup, 1/2-TON Blazer / Jimmy	0"-3"	spindle	8005	2104HA	0-2"		8505	2212HF
		4"-5"	springs	8005	2103HA	3-6"		8511	2208HF
63-72	1/2-TON C-10 Pickup	0"-3"	spindle	8005	2104HA	0-1"			2210AA
		1"-3"	springs	8005	2103HA	2-5"		8508	2208AA
Chevrolet 3/4 Ton Fullsize Truck 2 WD Applications									
01-10	1500HD / 2500HD All cabs	0"-2"	spindles	8013	10103H	0"-4"		8504	2210FF
		1"-2"	keys	8013	10103H	5"-7"		8505	2210FF
97-00	3/4 & 1-TON Single Rear Wheel-8 Lug Only & Crew Cab	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-8"		8502	2212IF
90-00	3/4 C-2500 Ext. & Crew Cab Single Rear Wheel-8 Lug Only	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-8"		8502	2212IF
88-98	3/4-TON C-2500 ALL EXCEPT: 8-LUG	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-7"		8502	2212IF
Chevrolet 1 Ton Fullsize Truck 2 WD Applications									
02-10	3500HD All cabs	0"-2"	spindles	8013	10103H	0"-4"		8504	2210FF
		1"-2"	keys	8013	10103H	5"-7"		8505	2210FF
97-00	1-TON SINGLE WHEEL 8-LUG.	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-8"		8502	2212IF
97-00	1-TON C-3500 Std./Ext Cab & Dually.	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-8"		8502	2212IF
97-00	1-TON C-3500 Crew Cab & Dually (8' Bed)	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-8"		8502	2212IF
92-96	1-TON C-3500 Crew Cab	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF

						5-8"		8502	2212IF
90-96	1-TON C-3500 Ext. Cab & Dually	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
88-89	1-TON C-3500 Ext. Cab & Dually	0"-3"	spindles	8000	10103I	0-1"		8500	2216IF
		2"-5"	springs	8006	10102I	2-4"		8535	2214IF
						5-8"		8502	2212IF
75-91	1-TON C-30 Crew Cab & Dually Only	0"		8005	2104HA	0-2"		8502	2212IF
		2"-4"	springs	8005	2103HA	2-4"		8506	2209IF
Chevrolet Fullsize Truck 4 WD Applications									
07-13	1/2-TON Silverado/Sierra (struts offer 2" lift to 2" lowering function in 1/2" increments)	+2" to -2"	OEM springs		25003	0-1"		8536	2214FF
		1"-4"	spindles		25003	2-4"		8504	2212FF
						5-7"		8510	2210FF
99-06	1/2-TON Silverado/Sierra Std. & Ext. Cab Short Bed Only (with factory equip. front coil spring)	0"-2"	spindles	8521	310400	0-1"		8536	2214FF
		2"-4"	keys	8521	310400	2-4"		8504	2212FF
88-98	1/2 Ton C-1500 Std. & Ext. Cab	1"-3"	keys	8519	2105GD	0-1"		8500	2216IF
						2-4"		8502	2214IF
Chevrolet SUV 2 WD Applications									
07-13	Tahoe / Yukon / Yukon XL / Suburban / Avalanche Without Factory Autoride Shocks (struts offer 2" lift to 2" lowering function in 1/2" increments)	+2" to -2"	OEM springs		25003	+1" to 0"			2414FF
		1"-4"	spindles		25003	1-2"		8522	2412FF
						3-4"		8522	2410FF
07-13	Suburban/Yukon XL with Factory Autoride Shocks (shocks offer 2" lift to 2" lowering function in 1/2" increments)	+2" to -2"	OEM springs		25003	+1" to 0"			2414FF
		1"-4"	spindles		25003	1-2"		8522	2412FF
						3-4"		8522	2410FF
07-13	Chevy Avalanche Without Factory Autoride Shocks (shocks offer 2" lift to 2" lowering function in 1/2" increments)	+2" to -2"	OEM springs		25003	+1" to 0"			2414FF
		1"-4"	spindles		25003	1-3"		8522	2412FF
						4-5"		8522	2410FF
00-06	Tahoe / Yukon / Suburban / Yukon XL Without Factory Premium Ride Shocks	0"-2"	spindles	8521	310400	0-2"		8522	2412FF
		2"-4"	keys	8521	310400	3-4"		8522	2410FF
00-06	Chevy Avalanche Without Factory Premium Ride Shocks (Including Z71)	0"-2"	spindles	8521	310400	0-3"		8522	2412FF
		2"-4"	keys	8521	310400	4-5"		8522	2410FF
02-09	Trailblazer/Envoy (struts offer 1" lift to 2" lowering function in 1/2" increments)	+1" to -2"	OEM springs		25011	0-1"		8524	2212DG
						2-3"		8532	2210DG
03-06	SSR	+1" to -2"	OEM springs		25011	0-1.5"		8532	2210DG
92-99	Suburban 1/2-TON (2-WD)	0"-2"	spindles	8000	10103I	+1 to -1"		8535	2414IF
		2"-5"	springs	8006	10102I	2-4"		8502	2412IF
						5-7"		8506	2209IF
92-98	Suburban 3/4-TON 2 WD (6-LUG)	0"-2"	spindles	8000	10103I	+1 to -1"		8535	2414IF
		2"-5"	springs	8006	10102I	2-4"		8502	2412IF
						5-7"		8506	2209IF
95-99	Tahoe / Yukon 4 Door Only	0"-2"	spindles	8000	10103I	+1 to -1"		8535	2414IF
		2"-5"	springs	8006	10102I	2-3"		8502	2412IF
						4-5"		8506	2209IF
95-99	Tahoe / Yukon 2 Door Only	0"-2"	spindles	8000	10103I	+1 to -1"		8535	2414IF
		2"-5"	springs	8006	10102I	2-4"		8502	2412IF
						5-6"		8506	2209IF
73-91	Suburban 1/2-TON 1-1/4" Rotor	0"-3"	spindles	8005	2104HA	0-1"		8505	2212HF
		2"-4"	springs	8005	2103HA	5-6"		8511	2208HF
Chevrolet SUV 4 WD Applications									
07-13	Tahoe / Yukon / Yukon XL / Suburban / Avalanche Without Factory Autoride Shocks (struts offer 2" lift to 2" lowering function in 1/2" increments)	+1" to -2"	OEM springs		25003	+1" to 0"			2414FF
		1"-4"	spindles		25003	1-2"		8522	2412FF
						3-4"		8522	2410FF
07-13	Tahoe/Suburban/Yukon XL, & Avalanche with Autoride (struts offer 2" lift to 2" lowering function in 1/2" increments)	+1" to -2"	OEM springs		25003	+1" to 0"			2414FF
		1"-4"	spindles		25003	1-2"		8522	2412FF
						3-4"		8522	2410FF
07-13	Chevy Avalanche Without Factory Autoride Shocks (struts offer 2" lift to 2" lowering function in 1/2" increments)	+1" to -2"	OEM springs		25003	+1" to 0"			2414FF
		1"-4"	spindles		25003	1-3"		8522	2412FF
						4-5"		8522	2410FF
00-06	Chevy Avalanche Without Factory Premium Ride Shocks (Including Z71)	0"-2"	spindles	8521	310400	0-2"		8522	2412FF
		2"-4"	keys	8521	310400	3-4"		8522	2410FF
00-06	Tahoe / Yukon / Suburban / Yukon XL Without Factory Premium Ride Shocks	0"-2"	spindles	8521	310400	0-3"		8522	2412FF
		2"-4"	keys	8521	310400	4-5"		8522	2410FF
95-99	Tahoe, Yukon, Escalade & Denali (4 door only)	0"-3"	keys	8519	2105GD	+1 to -1"		8535	2414IF
				8519	2105GD	2-4"		8502	2412IF
92-99	Suburban K-1500 only	0"-3"	keys	8519	2105GD	+1 to -1"		8535	2414IF
				8519	2105GD	2-4"		8502	2412IF
92-99	Tahoe, Yukon (2 door only)	0"-3"	keys	8519	2105GD	+1 to -1"		8535	2414IF
				8519	2105GD	2-4"		8502	2412IF
92-94	Blazer Full Size (4 door only)	0"-3"	keys	8519	2105GD	+1 to -1"		8535	2414IF

				8519	2105GD	2-4"		8502	2412IF
Chevrolet Van Applications									
85-02	Astro & Safari Van 2-WD	2"-4"		8000	10103I	2-4"		8532	2210DD
Dodge Truck & SUV 2 WD Applications									
98-03	Durango	0"		8006	10102I	0-1"			2214DD
		1"-3"	springs	8009	10101I	2"		8524	2212DD
97-04	Dakota (All Cabs)	0"		8006	10102I	0-1"			2214DD
		1"-3"	springs	8009	10101I	2-4"		8524	2212DD
97-04	Dakota R/T	1"	springs	8009	10101I	0-1"			2214DD
						2"		8524	2212DD
87-96	Dakota	0"-2"	spindles	8006	10102I	0-1"			2212ID
		2"-4"	springs	8009	10101I	2-4"		8513	2210ID
09-13	Ram 1500 Std. & Quad CAB	0"			10104I	0-2"			2215FF
		1"-3"	springs	8000	10103I	3-5"		8504	2212FF
02-08	Ram 1500 Std. & Quad CAB	0"		8001	10603I	0-2"		8536	2215FF
		1"-3"	springs	8006	10602I	3-5"		8504	2212FF
94-01	Ram 1500 Std. & EXT CAB.	0"-3"	spindles	8004	10603F	0-1"		8536	2215FF
		3"-5"	springs	8010	10602F	2-4"		8504	2212FF
						5-7"		8510	2209FF
94-02	Ram 2500 & 3500 V-10 & Diesel	0"		8004	10603F	0-1"		8536	2215FF
		1"-3"	springs	8010	10602F	2-4"		8504	2212FF
Ford Truck & SUV 2 WD Applications									
98-03	Ford Ranger Std. Cab and Ext. Cab	3"	3"	8000	10103I	2-4"		8514	2210HE
89-97	Ford Ranger Std. & Ext. Cab	2"-5"	I-beam	8013	10103H	4"-5.5"		8514	2210HE
04-13	Ford F150 2WD All Cabs (struts offer 1" lift to 3" lowering function in 1/2" increments)	+1 to -3"	OEM Springs		25001	0-1"		8537	2214EE
		1"-4"	Spindles		25001	2-3"		8523	2213EE
						4-5"		8523	2211EE
97-03	Ford F150, F250 Light Duty (All Cabs)	0"-2"	spindles	8014	10104I	0-1"		8518	10314B
		3"-5"	springs	8000	10103I	2-4"		8518	10311B
						6"		8518	10309B
97-03	Ford Lightning & Harley Series	0"-2"	spindles	8014	10104I	0-1"		8518	10311B
		3"-5"	springs	8000	10103I	2-3"		8518	10309B
87-96	Ford F150 Std. & Ext. Cab.	3"	I-beam	8002	10104B	1-4"		8503	2211HB
		2"-5"	springs	8002	10103B	7"		8509	2208HB
87-98	F-250/350 Std./Ext./Crew Cab (Dually only)	1"-3"	springs	8002	10103B	2-4"		8503	2211HB
97-02	Ford Expedition, Navigator (2WD)	0"-2"	spindles	8014	10104I	0"		8503	2211HB
		2"-3"	springs	8000	10103I	1-3"		8509	2208HB
Ford Truck 4 WD Applications									
04-13	Ford F150 4WD All Cabs (lifting shock 25002 offers 2" lift up to 2" lowering in 1/2" steps) (lowering strut 25001 offers 2" to 4" lowering in 1/2" increments)	+2 to -2"	OEM Springs		25002	0-1"	OEM Blocks		2216EE
		0"-4"	Spindles		25002	1-2"		8537	2214EE
		-2"-4"	OEM Springs		25001	3-5"		8523	2213EE
97-03	Ford F 150 (All Cabs)	0"-3"	keys	8024	10103D	0-1"			10314B
						2-4"		8518	10311B
Import Truck & SUV 2 WD Applications									
96-03	Isuzu Hombre (4 & 6 Cyl.)	0"-2"	spindles	8017	10102I	0-3"	blocks	8502	2412IF
		2"-5"	springs	8007	10101I	3-5"	leafs	8530	2410IF
98-04	Mazda B-2300/3000/4000 Std. & Ext Cab.	3"	springs	8000	10103I	3"		8514	2210HE
94-97	Mazda B-2300/3000/4000 Std. & Ext. Cab	2"-5"	spindles	8013	10103H	4-5.5"		8514	2210HE
83-97	Mitsubishi Pickup Series	2.5"	springs	8000	10103I	3"		8517	2209HH
04-10	Nissan Titan	+2" to -2"	OEM Springs		25009	0-1"			2313FL
						2-4"			2310FL
98-03	Nissan Frontier ALL EXCEPT: Crew Cab	2"	spindles	8008	10102C	3"		8517	2209HH
07-11	Toyota Tundra (All except TRD)	+2" to -2"	OEM Springs		25010	0-1"			10314NE
						2-4"			10311NE
84-95	Toyota Pickup	2"	spindles	8000	10103I	3"		8517	2209HH

Note "spindles" = these shocks are designed for OEM replacement, 1" spring or spindle only lowerings

Note "springs" = for any 2-3" spring or 2-5" spring/spindle lowering we recommend shorter shocks